




frequently asked questions

LCD ELITE CHART PLOTTER

“How do I connect the B&G WAAS GPS Antenna to the LCD Elite Chart Plotter?”



B&G WAAS GPS Antenna

Wiring

WAAS Antenna to LCD Elite Chart Plotter

WAAS GPS Antenna Cable	LCD Elite Power/Data Cable	12V Power Cable	Function
Red	Red	Red	+12V Power Supply
Black & Yellow	Black & Yellow	Black	0V and NMEA Ground
White	Green	- - -	GPS NMEA + Signal

---000000000---

B&G Customer Support
 Premier Way
 Abbey Park
 ROMSEY
 SO51 9DH
 UK