



frequently asked questions

Network Wind 283 to 496 MHU Upgrade

Product: 496 Mast Head Unit

Part Number: 496-00-001

“How do I alter the wind speed Hz/knot values to work with my new 496 MHU?”

The masthead unit originally fitted, as part of the Network Wind System was a Type 283. This unit is no longer available and has been replaced by the Type 496 MHU. The two units differ not only in physical appearance, but also in the Hz (frequency) of their wind speed output to the display.

The following procedure will reconfigure an existing display to read the adjusted Hz values supplied by the replacement 496 MHU.

Procedure:

1. Press the two outer buttons together (APP. & LIGHTS) to access the Diagnostic Mode.
2. Using the Up/Down (APP./TRUE) buttons, scroll through the options until **83** is displayed.
3. Press the Enter (LIGHTS) button to select this option.
4. Using the Up/Down buttons, scroll through the options until **13** is displayed.
5. Press the Enter button to select this option.
6. Using the Up/Down buttons, scroll through the options until **go** is displayed.
7. Press the **Enter** button to confirm the selection

The display will now return to its standard mode of operation, and the reconfiguration is complete.

B&G Customer Support
Premier Way
Abbey Park
Romsey
Hampshire
SO51 9DH
UK