

# addendum

---

## NMEA FFD and non-NMEA FFD Wiring

---

<b>Products:</b>	240-00-026	h2000 non-NMEA FFD
	240-00-028	h2000 NMEA FFD
<b>Serial Number:</b>	FFDNH054001 onwards	

---

### INTRODUCTION

With the introduction of the new NMEA and non-NMEA FFDs, it is important to note that the wiring has changed:

### Remote Button

The Remote Button is no longer supported by the new FFD platforms. Instead, the Yellow wire is now used for Version 2.xx NMEA compatibility. Additionally, do not cut back the Yellow wire even on non-NMEA FFDs. The Yellow wire is required for flash re-programming of the memory

### NMEA FFD Wiring

#### NMEA Input

NMEA Input (+):	Brown
NMEA Input (-):	Blue

#### NMEA Output Version 1.5

NMEA Output (+):	Violet
NMEA Output (-):	Black

#### NMEA Output Version 2.xx

NMEA Output (+):	Violet
NMEA Output (-):	Yellow

<ends>